

ACCESSORIES CATALOGUE



Home Sewing Machine Accessories

Feb. 2021 Edition

How to check your machine model

◆Label on the machine

Check the electrical rating label on the back of the machine.



In the case of a label with product code

The product code is the model name.

*Model HC500-00 is not.




In the case of a label without product code

Model is the model name.



◆Instruction manual

Check the cover of the instruction manual.



Machine model series

HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
HZL-UX8	DX-4000QVP	HZL-NX7 DX-3000QVP	DX-2000QVP HZL-DX7 HZL-DX5	HZL-F600 HZL-F400 HZL-F300
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
HZL-G220 HZL-G120 HZL-G210 HZL-G110	HZL-80HP HZL-70HW HZL-60HR	HZL-LB5100 HZL-LB5020	HZL-K85 HZL-K65	HZL-357ZP HZL-355ZW HZL-353ZR
HZL-27Z/29Z	HZL-12Z			
HZL-27Z HZL-29Z	HZL-12Z			

Standard Presser Foot

This Standard presser foot is used for sewing straight stitches and zigzag stitches. It can be used to sew lightweight to heavyweight materials.

The wide needle entry opening allows this presser foot to be used for a variety of fabrics and applications, from straight stitches to zigzag stitches.

Press the black button to keep the presser foot horizontal in order to smoothly begin sewing at a thick seam.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245085*		40197188**	40057923	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40057923	40165250	40169908	40051131	40151600
HZL-27Z/29Z	HZL-12Z			
40051131	40130228			


* Matte type and for JUKI Smart Feed. ** For JUKI Smart Feed. Matte type (40245085) is available, too.

Overcasting Presser Foot (Overedge Foot)

This presser foot is used to sew overcasting in order to prevent the cut edges of fabric from fraying.

Sew with the edges of the fabric aligned with the guide. The prong in the opening of the presser foot presses down the edge of the fabric to prevent puckering. In addition, the amount of thread going into the stitching is adjusted by the thread crossing the prong, creating a clean finish with little shrinkage.

This presser foot cannot be used to sew zigzag stitches or overcasting by 3-point zigzag.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080960				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40110163	40145869	40169900	40117901	40145869
HZL-27Z/29Z	HZL-12Z			
40050948	—			

Buttonhole Presser Foot

This presser foot is used to automatically sew buttonholes.

You can sew buttonholes of the appropriate size by simply placing the button in the button holder of the presser foot. (Not available with some sewing machines.)



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080966				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40110162	40165251	40169879	40117900	40151623
HZL-27Z/29Z	HZL-12Z			
40088436				

Decorate Stitch Presser Foot (Manual BH Presser Foot/Satin Stitch Foot)

This presser foot is used for sewing satin stitches, decorative stitches and letters.

The groove along the bottom of this presser foot ensures that the presser foot does not catch on the stitching, ensuring the fabric will be smoothly fed.

Use to accurately sew a buttonhole near a thick seam that is hard to reach. Also Used to Manually Create Oversize Buttonholes.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40240768*		40112905**	40112905	A9828-008-0A0
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40112905	40145868	40169901	40130234	40145868
HZL-27Z/29Z	HZL-12Z			
—				

* Matte type and for JUKI Smart Feed. Normal clear type (40112905) is available, too.

** Normal clear type. Matte type and for JUKI Smart Feed (40240768) is available, too.

Zig Zag Presser Foot

This presser foot is used for sewing satin stitches, decorative stitches and letters.

The groove along the bottom of this presser foot ensures that the presser foot does not catch on the stitching, so the fabric will be smoothly fed.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—			40117722	—
HZL-27Z/29Z	HZL-12Z			
—				

Button Attaching Presser Foot

This presser foot is used for holding a button in place and attaching it using the zigzag stitch.

Be sure to first lower the feed dog so the fabric is not fed and adjust the zigzag width so the needle enters the holes in the button.
To create a shank for the button, insert an awl or another similar object into the groove in the presser foot before sewing on the button so that the stitching will create a loop suitable for the thickness of the fabric.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080969				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080969	40151630	—	40116156	40151630
HZL-27Z/29Z	HZL-12Z			
40116156	—			

Feed Dog Cover

This cover is used for button attaching or free-motion sewing.

It covers the feed dog so that the material is not fed. Even a sewing machine without a drop feed function, you can attach the buttons or sew free-motion.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
40107933	—			

Zipper Presser Foot

This presser foot is used for closely sewing along the edges of a zipper.

Since this presser foot has a pin on the left side and on the right side for attaching it to the presser foot holder, you can attach this presser foot on either side of the needle, depending on which side of the zipper is being sewn.

This presser foot can cleanly sew along the edges of the zipper without hitting the teeth.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40240683*		A9823-010-0A0**	A9823-010-0A0	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
A9823-010-0A0	40151622	40169903	40117903	40151622
HZL-27Z/29Z	HZL-12Z			
40050946	40152343			


* Matte type and for JUKI Smart Feed. Normal type (A9823-010-0A0) is available, too.

** Normal type. Matte type and for JUKI Smart Feed (40240683) is available, too.

Adjustable Zipper Foot

This presser foot is used for closely sewing along the edges of a zipper or piping cord.

The position of the adjustable zipper presser foot can be changed over to the right and left of the needle to allow the sewing machine to sew the material while avoiding its thicker part such as a zipper.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40206252	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40206252		—	40206252	
HZL-27Z/29Z	HZL-12Z			
40206252				

Narrow Zipper Foot

This presser foot is used for sewing the very edge of the zipper, and sewing piping and D-ring that has a more height than the fabrics.

Since the width of the narrow zipper foot is small, the operator can easily observe the material during sewing. It has two (right and left) recesses on its undersurface, you can sew higher portions of the material while avoiding those portions. Both the right and left sides of the zipper can be sewn only by changing the position of the needle base line. The mounting portion of this presser foot is placed at its center, so the stable feed of the material is ensured.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40219624				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40219624	—			
HZL-27Z/29Z	HZL-12Z			
—				

Invisible Zipper Foot

This presser foot is used for inserting a concealed zipper.

Since this presser foot lifts the teeth of the zipper as they are fed through the groove along the bottom of the presser foot, you can closely sew along the edges of the zipper teeth.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080955				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080955	—		40117861	—
HZL-27Z/29Z	HZL-12Z			
—				

Blind Stitch Presser Foot (Blind Hem Foot)

This presser foot is used for sewing blind hem stitches, which are sewn along the hems of pants and skirts to be invisible from the right side of the fabric.

By sewing with the fabric fold aligned on the guide of this presser foot, only a few threads of the fabric will be uniformly caught in the stitch. Adjust the needle entry point or guide position according to the fabric before sewing.

You can also use this presser foot as a guide when changing the needle position for hemstitching in a straight line.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40112904				40080961
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40112904	40145872	40169902	40117902	40145872
HZL-27Z/29Z	HZL-12Z			
40050947	—			

Smooth Presser Foot

This presser foot is used for materials that do not feed well and are difficult to sew, such as vinyl-coated fabric and leather.

This presser foot, made of a fluorocarbon resin, smoothly feeds even vinyl-coated material and leather fabrics which may stick to a standard presser foot and are difficult to sew.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40248701*		40079312**	40079312	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40079312	—		40079312	—
HZL-27Z/29Z	HZL-12Z			
—				

* For JUKI Smart Feed. Normal type (40079312) is available, too.

** Normal type. For JUKI Smart Feed (40248701) is available, too.

Roller Foot

This presser foot is used for materials that do not feed well, such as vinyl-coated fabric, leather and terry cloth.

The rollers at the front and back of this presser foot prevent it from sticking to or bunching fabrics for perfect seams.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40117711				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40117711		—	40117711	
HZL-27Z/29Z	HZL-12Z			
40117711				

Rolled Hemming Presser Foot

This presser foot is used for sewing the edge of fabric while folding it twice to a narrow width about 1/8" (3 mm).

The spiral guide of this presser foot rolls the edge of the fabric to create a narrow rolled hem.

This presser foot can be used on light-weight to medium-weight fabric. Since the fabric can be uniformly folded twice without ironing, this presser foot is useful for finishing ruffles and handkerchief edges.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080958				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080958	40145870	—	40117710	40145870
HZL-27Z/29Z	HZL-12Z			
40117710	40141258			

Hemming Presser Foot for Zigzag

This presser foot is used for sewing the edge of fabric with a zigzag stitch while folding the fabric twice to a narrow width.

The spiral guide of this presser foot rolls the edge of the fabric while the narrow rolled hem is sewn with a zigzag stitch.

This presser foot can sew thin and solid edging.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080957				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080957	—			
HZL-27Z/29Z	HZL-12Z			
—				

Straight Stitch Presser Foot

This presser foot is used for sewing the straight stitch with the center needle position.

The guidelines on the right side at the front of the presser foot allow you to check the positions at about 0.1", 0.2", 0.3" (3, 5 or 7 mm) from the needle.

Since the needle drops into a small round opening, the seam is stabilized to create a perfect straight stitch.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245088*		40201410**	—	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—	40145874	—	40116154	40145874
HZL-27Z/29Z	HZL-12Z			
—				

* Matte type and for JUKI Smart Feed.

** For JUKI Smart Feed. Matte type (40245088) is available, too.

Binder Presser Foot

This presser foot is used for folding bias tape in four while edging fabric at a width of about 0.2" (5 mm).

After tape with a width of about 0.75" to 1.0" (22 to 25 mm) is passed through the guide, this presser foot creates double-fold tape with a width of about 0.2" (5 mm) and sews it to bind the fabric.

Single-fold tape with a width of about 0.4" to 0.5" (10 to 13 mm) can also be used.

You can move the guide to the left or right to adjust the needle entry point.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080954				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080954	—			
HZL-27Z/29Z	HZL-12Z			
—				

Pintuck Foot Narrow

This presser foot is used for sewing narrow pintucks on blouses and handkerchiefs using two needles.

When sewing pintucks in parallel, the 9 slits on the bottom of the presser foot can be used as a guide.

Pintucks are suited to light-weight soft materials.

Pintucks of stable shape can be produced while putting a cord in each pintuck.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40206244				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—	40206244	—	—	40206244
HZL-27Z/29Z	HZL-12Z			
—				

Pintuck Foot Wide

This presser foot is used for sewing wide pintucks on blouses and handkerchiefs using two needles.

When sewing pintucks in parallel, the 7 slits on the bottom of the presser foot can be used as a guide.

Pintucks are suited to light-weight soft materials.

Pintucks of stable shape can be produced while putting a cord in each pintuck.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40206248				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—	40206248	—	—	40206248
HZL-27Z/29Z	HZL-12Z			
—				

Walking Foot

This presser foot is used for stretch fabrics (such as knits), hard-to-feed materials (such as vinyl-coated fabric) and unevenly fed material (such as quilting or fabric with a nap).

This presser foot is equipped with an upper feed dog that works together with the feed dog of the sewing machine to feed the material in order to prevent bunched stitching and uneven feeding.

By inserting the quilt guide bar, this presser foot can be used to quilt equally spaced seams.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40080963	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080963	40145876	40169917	40117721*	40145876
HZL-27Z/29Z	HZL-12Z			
—				

* Cannot use with quilt guide

Patchwork Presser Foot

This presser foot is used for piecing together patchwork with a seam allowance of 1/4" (6.4 mm) or 1/8" (3.2 mm).

Always ensure needle is set to center straight stitch. Align the edge of the fabric with the outer presser foot guide for a seam allowance of 1/4" or with the inner presser foot guide for a seam allowance of 1/8". There are also marks at a 1/4" spacing at the front and back of the presser foot, allowing you to see the width of the seam allowance before and after needle entry.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245092*		40197827**	40080959	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080959	—		40117712	—
HZL-27Z/29Z	HZL-12Z			
40117712	—			

* Matte type and for JUKI Smart Feed.

** For JUKI Smart Feed. Matte type (40245092) is available, too.

1/4" Guide Foot

This presser foot is used for piecing together patchwork with a seam allowance of 1/4" (6.4 mm).

Always ensure needle is set to center straight stitch. Align the edge of the fabric with the presser foot guide to easily sew with a seam allowance of 1/4" (6.4 mm).

Since the needle drops into a small round opening, the seam is stabilized to create a perfect straight stitch.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245094*		40197829**	40164071	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40164071	—			
HZL-27Z/29Z	HZL-12Z			
—				

* Matte type and for JUKI Smart Feed. ** For JUKI Smart Feed. Matte type (40245094) is available, too.

7mm Guide Foot

This presser foot is used for piecing together patchwork with a seam allowance of 7 mm.

Always ensure needle is set to center straight stitch. Align the edge of the fabric with the presser foot guide to easily sew with a seam allowance of 7 mm.

Since the needle drops into a small round opening, the seam is stabilized to create a perfect straight stitch.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245096*		40197832**	—	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

* Matte type and for JUKI Smart Feed. ** For JUKI Smart Feed. Matte type (40245096) is available, too.

Presser Foot with Guide

The marks at a 0.07" (2 mm) spacing on this presser foot can be used as guides for stitching.

On the right side of the presser foot, there are guidelines at a 2 mm spacing from 0 to 2 cm from the center of the needle entry opening (center needle position).

This presser foot is useful when sewing parallel straight or decorative stitching.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080952				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080952	—			
HZL-27Z/29Z	HZL-12Z			
—				

Edge Sewing Presser Foot

This presser foot is used for stitching seam lines, such as with Stitch-in-the-ditch sewing for patchwork quilts and concealed seams on clothes.

The long guide at the center of the presser foot fits perfectly in the seam line to stabilize stitching.

You can also use this presser foot as a guide when changing the needle position for hemstitching in a straight line.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245090*		40080965**	40080965	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080965	—			
HZL-27Z/29Z	HZL-12Z			
—				


* Matte type and for JUKI Smart Feed. Normal type (40080965) is available, too.

** Normal type. Matte type and for JUKI Smart Feed (40245090) is available, too.

Compact Guide Edge Sewing Foot

This presser foot is used for patchwork quilting, edge stitching during dressmaking (in the case of sewing waistbands and neckbands), outline quilting and single lap stitching.

This presser foot has a shorter guide at its center. With this shorter guide, smoother feed of the material is promised. Furthermore, it is expected to reduce uneven material feed. The marks on the left side of the presser foot will be the guide for the outline quilting. By changing the needle base line, you can sew the single lap stitching with ease.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40219628				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40219628	—			
HZL-27Z/29Z	HZL-12Z			
—				

Quilt Presser Foot

This presser foot is used for free-motion quilting.

With the feed dogs lowered, you can freely move the fabric to draw using stitching.

Use the screw to adjust the height of the presser foot according to the thickness of the fabric, so the fabric moves smoothly.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40224352*			40080964	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080964	—			
HZL-27Z/29Z	HZL-12Z			
—				

* Use with adapter shank (40207583)

Quilt Presser Foot (for Ruler)

This presser foot is used for free-motion quilting using a ruler.

With a distance of 1/4" (6.5 mm) from the needle entry point to the outer edge of the presser foot, sew using a ruler as a guide. The front of the presser foot is lowered, making it easier to see the needle area. Adjust the height of the presser foot according to the thickness of the fabric.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40197266			40201927	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40201927	—			
HZL-27Z/29Z	HZL-12Z			
—				

Quilt Presser Foot (Open Type)

This presser foot for free-motion sewing is open at the front so that the needle area is easy to see.

Use the screw to adjust the height of the presser foot according to the thickness of the fabric, so the fabric moves smoothly.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40224355*			40080949	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080949	—			
HZL-27Z/29Z	HZL-12Z			
—				

* Use with adapter shank (40207583)

Quilt Presser Foot (Zigzag Type)

This presser foot is used for free-motion sewing with zigzag stitches.

The wide needle entry opening allows this presser foot to be used for free-motion sewing with zigzag stitches. Since the presser foot moves up and down together with the movement of the needle, thick seams can easily be crossed.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—	Machine included	40080953*	40080953	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080953	40145873	40169916	40052013	40145873
HZL-27Z/29Z	HZL-12Z			
—				

* Use with adapter shank (40207583)

Open Toe Presser Foot

This presser foot is used for stitching appliqués or designs.

The wide opening at the front of this presser foot makes appliqués and designs easy to see, which is useful for curvy decorative stitching. The groove along the bottom of this presser foot ensures that the presser foot does not catch on the stitching, so the fabric will be smoothly fed.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080962				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080962	—			
HZL-27Z/29Z	HZL-12Z			
—				

Applique Presser Foot

This presser foot is used for stitching appliqués or designs.

Since the front and back of this presser foot are short and transparent, appliqués and designs are easy to see, and you can easily sew sharp curves.

The pin at the back keeps the presser foot horizontal, stabilizing it even when sewing appliqués.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080951				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080951	—			
HZL-27Z/29Z	HZL-12Z			
—				

Pearl Attaching Presser Foot

This presser foot is used for sewing on strands of pearls or beads.

Pass the strand of pearls or beads up to a diameter of 4 mm through the dome-shaped groove in the center of the presser foot, and then sew with a zigzag stitch.

This presser foot can also be used for sewing on thick cording, braiding or piping cord, even on curves.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080956				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080956	—			
HZL-27Z/29Z	HZL-12Z			
—				

Fringe Foot

This presser foot is used for forming loops or fringes to decorate workpieces.

This foot has a claw at its center. It is used for forming loops by laying the thread over the claw. This presser foot can be used for sewing decorative stitches on workpieces by making three-dimensional thread loops and fringes on the edge of the fabric with your favorite threads.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40219620				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40219620	—			
HZL-27Z/29Z	HZL-12Z			
—				

Cording and Embroidery Presser Foot

This presser foot is used for free-motion sewing of cording.

This presser foot has a hole for supplying cording to be sewn over. With the feed dog lowered, you can freely move the fabric to create simple embroidery with cording.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40224357*			40080950	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080950	—			
HZL-27Z/29Z	HZL-12Z			
—				

* Use with adapter shank (40207583)

Cording Presser Foot (for 3 Cords)

This presser foot is used for sewing on up to three thin decorative cords or embroidery threads.

Pass threads through the three channels in front of the needle entry opening and sew them with the three-point zigzag stitch or decorative stitches in order to create three-dimensional decorations.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
A9829-880-0A0				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
A9829-880-0A0	40145871	—		40145871
HZL-27Z/29Z	HZL-12Z			
—				

7 Hole Cording Foot

With this presser foot, you can enjoy sewing of 3-dimensional decorative stitches using thin cords or embroidery threads (up to seven cords / threads) together.

This presser foot is provided with seven cord insertion holes of approximately 1 mm in diameter. As many as seven (1 to 7) thin cord(s) or embroidery thread(s) can be sewn using these holes while neatly arranging them in parallel (in the case of two or more cords / threads are used).



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40219632				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40219632	—			
HZL-27Z/29Z	HZL-12Z			
—				

Gathering Foot

This presser foot automatically creates gathers in the fabric.

Change the stitch length, thread tension and presser foot pressure to adjust the amount of fabric that is gathered.
You can also use this presser foot to sew two pieces of fabric together while creating gathers in only the lower piece.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40215902	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40215902		—	40215902	40145875
HZL-27Z/29Z	HZL-12Z			
40215902				

Adapter Shank

Detach the presser foot holder and use it for the presser foot to be used.

Can be used with the Quilt Presser Foot, Quilt Presser Foot (Open Type), Quilt Presser Foot (Zigzag Type), Cording and Embroidery Presser Foot.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40207583			—	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Quilt Guide

This guide is used for sewing equally spaced rows of stitching.

Insert this guide into the hole of the presser foot holder or the walking foot, and then sew while lightly tracing this guide along stitching. Adjust the spacing of the stitching by changing how far this guide is inserted.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40195922			A9833-550-0A0	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
A9833-550-0A0	40151624	40169918	A9833-550-0A0	40151624
HZL-27Z/29Z	HZL-12Z			
—				

Twin Needle

You can sew straight lines and decorative patterns in parallel with two needles with 0.07" (2 mm) spacing.

For beautiful decorative stitches two threads can be a perfect addition. Also it is used for sewing pintucks with the pintuck feet. Set the sewing machines with 2 needle settings with optional functions. Not all stitches are approved for twin needle design.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40083061				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—	40145877	—		40145877
HZL-27Z/29Z	HZL-12Z			
—				

Dedicated Hook for Thick Thread Decoration

It is used when decorative sewing is performed with bobbin thread using thick thread or ribbon.

Wrap the thread you want to decorate around the bobbin and draw a pattern with pattern stitching or free motion.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40247203				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40247203	—			
HZL-27Z/29Z	HZL-12Z			
—				

Auxiliary Spool Pin (Additional Spool Pin)

This spool pin is used when another thread spool is needed for twin needle sewing or bobbin winding.

Use this spool pin with a thread spool for twin needle sewing, spare machine threading or bobbin winding.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40080967				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—	40165254	40169872	—	40151633
HZL-27Z/29Z	HZL-12Z			
—				

LED Pointer

With the LED pointer, you can start sewing without lowering the needle to check the sewing start position.

Expand your creativity with the LED pointer as a guide when aligning rows of patterns for sewing. Use with mounting base(40247204). You can also attach a borescope camera instead of the LED pointer. Easily share images and videos you are sewing to social media. *Please purchase a commercially available borescope camera.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40247205		—		
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Mounting Base

The mounting base allows you to attach the LED pointer, scope, and magnifying lens attachment to the sewing machine.

When you use the LED pointer, borescope camera and magnifier (flip-up type), use with this mounting base.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40247204		—		
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Magnifier (Flip-Up Type)

Use as a magnifying glass to enlarge the needle area.

When not in use, you can move it out of the way. Use with mounting base(40247204).




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40247079		—		
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Stitch Area Magnifier

This magnifier allows the needle area to be enlarged by approximately 1.4 times, making it easier to see.

This is useful for viewing the needle area or performing intricate operations.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—		40164074		—
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Thread Stand (for Two Spools)

This additional thread stand can be used with TWO large cross-wound cone style thread.

It is convenient for both top and bottom threads, or two needle sewing, too.

The specially designed thread guide that is also installed smoothly pulls the thread straight up.

When placing the hard case on the sewing machine, this thread stand and thread guide can be removed in a single step.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245194		—		
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Thread Stand

This additional thread stand can be used with large cross-wound cone style thread.

The specially designed thread guide that is also installed smoothly pulls the thread straight up.

When placing the hard case on the sewing machine, this thread stand and thread guide can be removed in a single step.




HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—		40208049	40163897	—
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Throat Plate for Straight Stitch

This needle plate designed specifically for straight stitching allows you to sew beautiful straight stitches.

This needle plate is used to sew the straight stitch with the center needle position.
Creates perfect needle feed for light weight fabrics or corner to corner stitching in patchwork piecing.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245153*		40205310*	—	40080968
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40080968**	—			
HZL-27Z/29Z	HZL-12Z			
—				


* Use with straight feed dog (40201411)

** HZL-G210/G110 Part No. 40080968 & 40064685(hook cover)

Magnetic Gauge

This gauge is used as a guide for the edge of the fabric when sewing with a fixed seam allowance. A magnet allows you to easily reposition the gauge.


A strong magnet holds this gauge in place on the needle plate. This gauge can also be used on household sewing machines with a metal needle plate.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
A9848-D25-0A0				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
A9848-D25-0A0				
HZL-27Z/29Z	HZL-12Z			
A9848-D25-0A0				

Ruler Kit (HZL type)

This quilting ruler is used for creating a pattern while stitching along with the quilt presser foot (for ruler).



Various patterns can be formed by combining basic lines and shapes. This kit contents straight, wave, hexagon, circle, feather shapes. Be sure to use this kit together with the presser foot for ruler. The thickness of these rulers are 3mm.

HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40209956				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40209956	—			
HZL-27Z/29Z	HZL-12Z			
—				

Ruler Set

This quilting ruler is used for creating a pattern while stitching along with the quilt presser foot (for ruler).




Various patterns can be formed by combining basic lines and shapes. This kit contents straight, wave, hexagon, circle, feather shapes. Be sure to use this kit together with the presser foot for ruler. The kit contents and shapes may differ.

HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
Please contact your local JUKI dealer			—	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Wide Table

This table enlarges the work surface, allowing you to comfortably sew large projects.

After removing the auxiliary bed, this table can easily be installed by fitting it into place.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40245154		40205305	J-F/TABLE	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
J-F/TABLE	J-H/TABLE	J-L/TABLE	J-E/TABLE	J-H/TABLE
HZL-27Z/29Z	HZL-12Z			
—				

Foot Controller with Foot Switch Function

This controller can be used to start/stop sewing and adjust the sewing speed with your foot.

Controlling the sewing machine with your foot leaves both of your hands free while sewing. You can trim threads and or do another operations by pressing on the another switch of the foot controller.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40205287			40144123	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Foot Switch Stopper

This stopper can be used for disabling the foot switch of the foot controller.

Installing this stopper on the foot controller disables the function that is activated by stepping on the controller with your heel.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40165358	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Foot Controller

This controller can be used to start/stop sewing and adjust the sewing speed with your foot.

Controlling the sewing machine with your foot leaves both of your hands free while sewing.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40107483*	40165257	40169914	40117706	Please contact your local JUKI dealer
HZL-27Z/29Z	HZL-12Z			
Please contact your local JUKI dealer				

* 40119192 for Korean version

Knee-lifting Lever

Increase efficiency by using your knees to lift and lower the presser foot without using Your hands.

Using your knee to push the lever to the right raises the presser foot, and when you return it will lower the presser foot.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
40070255				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
—				
HZL-27Z/29Z	HZL-12Z			
—				

Bobbin

These bobbins are designed specifically for JUKI household sewing machines.

Since the bobbin type differs depending on your sewing machine model, be sure to use the bobbin designed for your machine.



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
001141000000				
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
001141000000	40151627	40177365	A9834-030-0A0	40151627
HZL-27Z/29Z	HZL-12Z			
A9834-030-0A0	40130125			

Advanced Quilter's Kit

This set of presser feet is created specialty quilting and sewing as you advance in your sewing.

This set contains the following: Edge Sewing Presser Foot, Quilt Presser Foot (Open Type), Quilt Presser Foot (Zigzag Type), Open Toe Presser Foot, Appliqué Presser Foot, Pearl Attaching Presser Foot



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40091174	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40091174	—			
HZL-27Z/29Z	HZL-12Z			
—				

Heavy User Kit

This set of versatile and useful presser feet that will meet the needs of even advanced everyday users.

This set contains the following: Button Attaching Presser Foot, Invisible Zipper Foot, Rolled Hemming Presser Foot, Binder Presser Foot, Presser Foot with Guide, Cording and Embroidery Presser Foot



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40091175	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40091175	—			
HZL-27Z/29Z	HZL-12Z			
—				

Creative Set

This set of presser feet and bobbins are perfect for creative embellishment with your sewing machine.

This set contains the following: Appliqué Presser Foot, Cording and Embroidery Presser Foot, Pearl Attaching Presser Foot, Cording Presser Foot (for 3 Cords), Presser Foot with Guide, Open Toe Presser Foot, Bobbin x5



HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
—			40183638	
HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
40183638	—			
HZL-27Z/29Z	HZL-12Z			
—				

Home Sewing Machine Accessories List

	HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
	HZL-UX8	DX-4000QVP	HZL-NX7 DX-3000QVP	DX-2000QVP HZL-DX7 HZL-DX5	HZL-F600 HZL-F400 HZL-F300
Standard Presser Foot	40245085 *1		40197188 *2	40057923	
Overcasting Presser Foot (Overedge Foot)			40080960		
Buttonhole Presser Foot			40080966		
Decorate Stitch Presser Foot (Manual BH Presser Foot/Satin Stitch Foot)	40240768 *3		40112905 *4	40112905	A9828-008- 0A0
Zig Zag Presser Foot			—		
Button Attaching Presser Foot			40080969		
Feed Dog Cover			—		
Zipper Presser Foot	40240683 *3		A9823-010- 0A0 *4	A9823-010-0A0	
Adjustable Zipper Foot		—		40206252	
Narrow Zipper Foot			40219624		
Invisible Zipper Foot			40080955		
Blind Stitch Presser Foot (Blind Hem Foot)			40112904		40080961
Smooth Presser Foot	40248701 *5		40079312 *6	40079312	
Roller Foot			40117711		
Rolled Hemming Presser Foot			40080958		
Hemming Presser Foot for Zigzag			40080957		
Straight Stitch Presser Foot	40245088 *1		40201410 *2	—	
Binder Presser Foot			40080954		
Pintuck Foot Narrow			40206244		
Pintuck Foot Wide			40206248		
Walking Foot		—		40080963	
Patchwork Presser Foot	40245092 *1		40197827 *2	40080959	

***1** Matte type and for JUKI Smart Feed.

***2** For JUKI Smart Feed. Matte type is available, too.

***3** Matte type and for JUKI Smart Feed. Normal type is available, too.

***4** Normal type. Matte type and for JUKI Smart Feed is available, too.

***5** For JUKI Smart Feed. Normal type is available, too.

***6** Normal type. For JUKI Smart Feed is available, too.

	HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
	HZL-UX8	DX-4000QVP	HZL-NX7 DX-3000QVP	DX-2000QVP HZL-DX7 HZL-DX5	HZL-F600 HZL-F400 HZL-F300
1/4" Guide Foot	40245094 *1		40197829 *2	40164071	
7mm Guide Foot	40245096 *1		40197832 *2	—	
Presser Foot with Guide			40080952		
Edge Sewing Presser Foot	40245090 *3		40080965 *4	40080965	
Compact Guide Edge Sewing Foot			40219628		
Quilt Presser Foot		40224352 *7		40080964	
Quilt Presser Foot (for Ruler)		40197266		40201927	
Quilt Presser Foot (Open Type)		40224355 *7		40080949	
Quilt Presser Foot (Zigzag Type)	—	Machine included	40080953 *7	40080953	
Open Toe Presser Foot			40080962		
Applique Presser Foot			40080951		
Pearl Attaching Presser Foot			40080956		
Fringe Foot			40219620		
Cording and Embroidery Presser Foot		40224357 *7		40080950	
Cording Presser Foot (for 3 Cords)			A9829-880-0A0		
7 Hole Cording Foot			40219632		
Gathering Foot		—		40215902	
Adapter Shank		40207583		—	
Quilt Guide		40195922		A9833-550-0A0	
Twin Needle			40083061		
Dedicated Hook for Thick Thread Decoration			40247203		
Auxiliary Spool Pin (Additional Spool Pin)			40080967		

***1** Matte type and for JUKI Smart Feed.

***2** For JUKI Smart Feed. Matte type is available, too.

***3** Matte type and for JUKI Smart Feed. Normal type is available, too.

***4** Normal type. Matte type and for JUKI Smart Feed is available, too.

***7** Use with adapter shank (40207583)

	HZL-UX8	DX-4000QVP	HZL-NX7	HZL-DX Series	Exceed(F) Series
	HZL-UX8	DX-4000QVP	HZL-NX7 DX-3000QVP	DX-2000QVP HZL-DX7 HZL-DX5	HZL-F600 HZL-F400 HZL-F300
LED Pointer	40247205		—		
Mounting Base	40247204		—		
Magnifier (Flip-Up Type)	40247079		—		
Stitch Area Magnifier	—		40164074		—
Thread Stand (for Two Spools)	40245194		—		
Thread Stand	—		40208049	40163897	—
Throat Plate for Straight Stitch	40245153 *8		40205310 *8	—	40080968
Magnetic Gauge	A9848-D25-0A0				
Ruler Kit (HZL type)	40209956				
Ruler Set	Please contact your local JUKI dealer			—	
Wide Table	40245154		40205305	J-F/TABLE	
Foot Controller with Foot Switch Function	40205287			40144123	
Foot Switch Stopper	—			40165358	
Foot Controller	—				
Knee-lifting Lever	40070255				
Bobbin	001141000000				
Advanced Quilter's Kit	—			40091174	
Heavy User Kit	—			40091175	
Creative Set	—			40183638	

*8 Use with straight feed dog (40201411)

	HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
	HZL-G220 HZL-G120 HZL-G210 HZL-G110	HZL-80HP HZL-70HW HZL-60HR	HZL-LB5100 HZL-LB5020	HZL-K85 HZL-K65	HZL-357ZP HZL-355ZW HZL-353ZR
Standard Presser Foot	40057923	40165250	40169908	40051131	40151600
Overcasting Presser Foot (Overedge Foot)	40110163	40145869	40169900	40117901	40145869
Buttonhole Presser Foot	40110162	40165251	40169879	40117900	40151623
Decorate Stitch Presser Foot (Manual BH Presser Foot/Satin Stitch Foot)	40112905	40145868	40169901	40130234	40145868
Zig Zag Presser Foot	—			40117722	—
Button Attaching Presser Foot	40080969	40151630	—	40116156	40151630
Feed Dog Cover	—				
Zipper Presser Foot	A9823-010-0A0	40151622	40169903	40117903	40151622
Adjustable Zipper Foot	40206252		—	40206252	
Narrow Zipper Foot	40219624	—			
Invisible Zipper Foot	40080955	—		40117861	—
Blind Stitch Presser Foot (Blind Hem Foot)	40112904	40145872	40169902	40117902	40145872
Smooth Presser Foot	40079312	—		40079312	—
Roller Foot	40117711		—	40117711	
Rolled Hemming Presser Foot	40080958	40145870	—	40117710	40145870
Hemming Presser Foot for Zigzag	40080957	—			
Straight Stitch Presser Foot	—	40145874	—	40116154	40145874
Binder Presser Foot	40080954	—			
Pintuck Foot Narrow	—	40206244	—		40206244
Pintuck Foot Wide	—	40206248	—		40206248
Walking Foot	40080963	40145876	40169917	40117721 *9	40145876
Patchwork Presser Foot	40080959	—		40117712	—

*9 Cannot use with quilt guide

	HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
	HZL-G220 HZL-G120 HZL-G210 HZL-G110	HZL-80HP HZL-70HW HZL-60HR	HZL-LB5100 HZL-LB5020	HZL-K85 HZL-K65	HZL-357ZP HZL-355ZW HZL-353ZR
1/4" Guide Foot	40164071	—			
7mm Guide Foot	—				
Presser Foot with Guide	40080952	—			
Edge Sewing Presser Foot	40080965	—			
Compact Guide Edge Sewing Foot	40219628	—			
Quilt Presser Foot	40080964	—			
Quilt Presser Foot (for Ruler)	40201927	—			
Quilt Presser Foot (Open Type)	40080949	—			
Quilt Presser Foot (Zigzag Type)	40080953	40145873	40169916	40052013	40145873
Open Toe Presser Foot	40080962	—			
Applique Presser Foot	40080951	—			
Pearl Attaching Presser Foot	40080956	—			
Fringe Foot	40219620	—			
Cording and Embroidery Presser Foot	40080950	—			
Cording Presser Foot (for 3 Cords)	A9829-880-0A0	40145871	—		40145871
7 Hole Cording Foot	40219632	—			
Gathering Foot	40215902		—	40215902	40145875
Adapter Shank	—				
Quilt Guide	A9833-550-0A0	40151624	40169918	A9833-550-0A0	40151624
Twin Needle	—	40145877	—		40145877
Dedicated Hook for Thick Thread Decoration	40247203	—			
Auxiliary Spool Pin (Additional Spool Pin)	—	40165254	40169872	—	40151633

	HZL-G Series	HZL-H Series	HZL-L Series	HZL-K Series	HZL-350Z Series
	HZL-G220 HZL-G120 HZL-G210 HZL-G110	HZL-80HP HZL-70HW HZL-60HR	HZL-LB5100 HZL-LB5020	HZL-K85 HZL-K65	HZL-357ZP HZL-355ZW HZL-353ZR
LED Pointer	—				
Mounting Base	—				
Magnifier (Flip-Up Type)	—				
Stitch Area Magnifier	—				
Thread Stand (for Two Spools)	—				
Thread Stand	—				
Throat Plate for Straight Stitch	40080968 *10	—			
Magnetic Gauge	A9848-D25-0A0				
Ruler Kit (HZL type)	40209956	—			
Ruler Set	—				
Wide Table	J-F/TABLE	J-H/TABLE	J-L/TABLE	J-E/TABLE	J-H/TABLE
Foot Controller with Foot Switch Function	—				
Foot Switch Stopper	—				
Foot Controller	40107483 *11	40165257	40169914	40117706	Please contact your local JUKI dealer
Knee-lifting Lever	—				
Bobbin	001141000000	40151627	40177365	A9834-030- 0A0	40151627
Advanced Quilter's Kit	40091174	—			
Heavy User Kit	40091175	—			
Creative Set	40183638	—			

***10** HZL-G210/G110 Part No. 40080968 & 40064685(hook cover)

***11** 40119192 for Korean version

	HZL-27Z/29Z	HZL-12Z			
	HZL-27Z HZL-29Z	HZL-12Z			
Standard Presser Foot	40051131	40130228			
Overcasting Presser Foot (Overedge Foot)	40050948	—			
Buttonhole Presser Foot	40088436				
Decorate Stitch Presser Foot (Manual BH Presser Foot/Satin Stitch Foot)	—				
Zig Zag Presser Foot	—				
Button Attaching Presser Foot	40116156	—			
Feed Dog Cover	40107933	—			
Zipper Presser Foot	40050946	40152343			
Adjustable Zipper Foot	40206252				
Narrow Zipper Foot	—				
Invisible Zipper Foot	—				
Blind Stitch Presser Foot (Blind Hem Foot)	40050947	—			
Smooth Presser Foot	—				
Roller Foot	40117711				
Rolled Hemming Presser Foot	40117710	40141258			
Hemming Presser Foot for Zigzag	—				
Straight Stitch Presser Foot	—				
Binder Presser Foot	—				
Pintuck Foot Narrow	—				
Pintuck Foot Wide	—				
Walking Foot	—				
Patchwork Presser Foot	40117712	—			

	HZL-27Z/29Z	HZL-12Z			
	HZL-27Z HZL-29Z	HZL-12Z			
1/4" Guide Foot	—				
7mm Guide Foot	—				
Presser Foot with Guide	—				
Edge Sewing Presser Foot	—				
Compact Guide Edge Sewing Foot	—				
Quilt Presser Foot	—				
Quilt Presser Foot (for Ruler)	—				
Quilt Presser Foot (Open Type)	—				
Quilt Presser Foot (Zigzag Type)	—				
Open Toe Presser Foot	—				
Applique Presser Foot	—				
Pearl Attaching Presser Foot	—				
Fringe Foot	—				
Cording and Embroidery Presser Foot	—				
Cording Presser Foot (for 3 Cords)	—				
7 Hole Cording Foot	—				
Gathering Foot	40215902				
Adapter Shank	—				
Quilt Guide	—				
Twin Needle	—				
Dedicated Hook for Thick Thread Decoration	—				
Auxiliary Spool Pin (Additional Spool Pin)	—				

	HZL-27Z/29Z	HZL-12Z			
	HZL-27Z HZL-29Z	HZL-12Z			
LED Pointer	—				
Mounting Base	—				
Magnifier (Flip-Up Type)	—				
Stitch Area Magnifier	—				
Thread Stand (for Two Spools)	—				
Thread Stand	—				
Throat Plate for Straight Stitch	—				
Magnetic Gauge	A9848-D25-0A0				
Ruler Kit (HZL type)	—				
Ruler Set	—				
Wide Table	—				
Foot Controller with Foot Switch Function	—				
Foot Switch Stopper	—				
Foot Controller	Please contact your local JUKI dealer				
Knee-lifting Lever	—				
Bobbin	A9834-030- 0A0	40130125			
Advanced Quilter's Kit	—				
Heavy User Kit	—				
Creative Set	—				